

Premium Shelf Kit With Custom Graphics


Instruction & Specification Sheet SD3200,SD3211, SD3221, SD3231

BEFORE YOU BEGIN

Note: It is recommended that you have someone help you assemble the Shelf Kit. Tools required: Small adjustable wrench.

Be sure to read all the instructions before attempting to assemble the Standard Shelf Kit.

- Carefully remove all parts from the carton and inspect each part. If a part appears to be damaged or missing, please contact Rosseto Customer Service.



STANDARD SHELF KITS*

Kit Number	Description
SD3200	Custom Catch Tray and Header Backing Graphics
SD3211	Coffee Catch Tray and Header Backing Graphics
SD3221	Candy Catch Tray and Header Backing Graphics
SD3231	Natural Foods Catch Tray and Header Backing Graphics

* All premium shelf kits include (1) Shelf SD3116, (1) Catch Tray Shelf with Grate SD3178, (1) Header SD3192, (9) PRO-BULK™ Dispensers DS101, (4) Hex Nuts, and (9) Push Pins GDM001.

REPLACEMENT PARTS

Part Number	Description
DS101	PRO-BULK™ Dispenser
SD3116	Main Shelf
SD3192	Header
SD3178	Catch Tray Shelf with Grate
SDS200-B	Custom Catch Tray Backing Graphics
SDS201-B	Coffee Catch Tray Backing Graphics
SDS202-B	Candy Catch Tray Backing Graphics
SDS203-B	Natural Foods Catch Tray Backing Graphics
SDS300-F	Custom Header Graphics
SDS311-F	Coffee Header Graphics
SDS312-F	Candy Header Graphics
SDS313-F	Natural Foods Header Graphics

NEED ASSISTANCE?

Customer Service Support: **847-763-1215**

Address: **3714 Jarvis Avenue Skokie, IL 60076**

Website: **www.rosseto.com**




Premium Shelf Kit With Custom Graphics


Instruction & Specification Sheet SD3200,SD3211, SD3221, SD3231

ASSEMBLING THE SHELF KIT


1. Choose a convenient height to install the Main Shelf that will hold the PRO-BULK™ dispensers.
Insert the tabs on the Shelf into the slots on each side the main frame and lock into position.




2. Attach the Graphics Panel to the Catch Tray Shelf as shown below using (6) Push Pins.



3. Attach the Catch Tray Shelf to the threaded pins on the underside of the Main Shelf as shown in Details A and B. below.



4. Secure the Catch Tray Shelf to the Main Shelf with (2) hex nuts on each side. Tighten the hex nuts using small adjustable wrench.




Premium Shelf Kit With Custom Graphics

Instruction & Specification Sheet SD3200,SD3211, SD3221, SD3231


ASSEMBLING THE HEADER

1. The Header Assembly should be mounted a minimum of 15.6 inches (39.6 cm) above the Main Shelf. See illustration below.


Insert the tabs on the Header Assembly into the slots on each side of the main frame and lock into position.



2. Attach the Header Graphics Panel to the Header Panel as shown below using (3) Push Pins.



3. Hang the assembled Header Graphics Panel on the pins on either side of the Header Assembly.




Premium Shelf Kit With Custom Graphics

Instruction & Specification Sheet SD3200,SD3211, SD3221, SD3231

ADDING THE PRO-BULK DISPENSERS

1. Slide the Dispenser into position making sure the flange on the base fits under the lip on the back of the Main Shelf.
2. Next, rotate the Dispenser down into position.
The Dispenser is now locked in position.



SPECIFICATIONS

ASSEMBLED DIMENSIONS	INCHES	CM
LENGTH	48"	121.9 cm
WIDTH	19.75"	50.1 cm
HEIGHT	32.1"	81.5 cm

WEIGHT 121 lbs/54.9 kg

CARE AND CLEANING

- DO NOT put any parts through dishwasher or dryer machine. ALWAYS use a non-abrasive sponge.
- DO NOT use any abrasive materials such as scrapers or metal-based brushes.
- DO NOT use harsh chemicals or abrasive cleaners.

Metal Care:

Wipe down with damp microfiber cloth and always wipe dry with a microfiber cloth. Store in a dry and well-ventilated location.

