


Multi-Chef™ Square Warmer with Round Soft Close Chafer

Instruction & Specification Sheet for Models SK088 and SK089

BEFORE YOU BEGIN

Be sure to read all the instructions before attempting to use the Multi-Chef Warmer. Proper care and maintenance will extend the life of your new Warmer. **Save these instructions for future reference.**

- Carefully unpack and inspect all parts. If a part appears to be damaged or missing, please contact Rosseto Customer Service.
- Handle all parts carefully when moving, storing, or cleaning to avoid damage. Be sure to follow the Care and Cleaning instructions.



PARTS DESCRIPTION

Multi-Chef Square Warmer with Round Soft Close Chafer

SK088	Black Matte Warmer with Stainless Steel Soft Close Chafer, 3 Fuel Holders, and Burner Stand
SK089	Stainless Steel Warmer with Stainless Steel Soft Close Chafer, 3 Fuel Holders, and Burner Stand

IMPORTANT SAFEGUARDS

When using the Warmer, basic safety precautions should always be observed, including the following:

- This Warmer is intended to be used for commercial applications such as in kitchens of restaurants, canteens, hospitals, and commercial enterprises; but not for continuous mass production of food.

IMPORTANT SAFEGUARDS

- Place the Multi-Chef Warmer on a flat, firm, dry surface. Do not operate the Warmer on a plastic or soft tablecloth.
- Do not overfill the Chafer to avoid contents from spilling over during use.
- Never let the Warmer operate without supervision.** Children should not operate the Warmer.
- Do not operate the Warmer in an area where gasoline, paint, or flammable liquids are used or stored.
- The Chafer may remain hot after use. Always let the Chafer cool before handling. Use gloves to avoid leaving finger prints on the Chafer.

OPERATING INSTRUCTIONS

- Place the Warmer Base on a flat, firm, dry and safe surface.
- Slide the Burner Stand into the Warmer Base. See figure at left.
- Place heat chafing fuel into the Fuel Holders. Fuel Holders may be placed at two different levels in the Burner Stand depending on desired heat control. Light the chafing fuel.
- Place the Chafer into the hole on top of the Warmer Base. The Warmer is now ready for use.
- The back of the Warmer Base has a large "opening" that has been designed specifically for easy placement of the Fuel Holder in the event that the chafing fuel needs to be changed during use.

CARE AND CLEANING

- Do not use any caustic cleaning agents or abrasive scrubbing pads on any part.
- All parts should be wiped with a warm, damp cloth and a mild nonabrasive soap solution.
- Wipe off the outside of the Warmer Base and the Soft Close Chafer with a soft cloth.
- Make sure that all parts are clean and dry before storing.

SPECIFICATIONS

ASSEMBLED DIMENSIONS	18 X 18.5 X 13 INCHES 45.72 X 47.00 X 33.02 CM
ASSEMBLED WEIGHT	27 lbs/12.25 kg

NEED ASSISTANCE?

Customer Service Support: **847-763-1215**

Address: **3714 Jarvis Avenue Skokie, IL 60076**

Website: **www.rosseto.com**

